

UNITECH SCALES AND MEASUREMENTS PVT. LTD.

Measurement Lab [Transducer Lab] -

Capacitance Measurement Trainer Module



www.unitechscales.com

E-mail: - support@unitechscales.com; sales@unitechscales.com

Mobile no : - +91-98452 22919 (Mr. Prasanna Kumar N.M) Mobile no : - +91-98450 70453 (Mr. Keshava Murthy M.N)

Phone no: - +91-80-2836 6999 | Fax no: - +91-80-2836 6745

Capacitance Trainer comprises of parallel plate/angular capacitor with dielectric medium air as sensor, mounted on the base plate with scale for displacement. Digital indicator is provided to read the change in capacitance in terms of displacement

Model : UITM-110 [Linear Displacement]

: UITM-111 [Angular Displacement]

Capacitance Sensor : Linear-Parallel plate capacitor

: Angular-Gang condensor.

Displacement : Linear-50mm

: Angular-0-90°

Indicator : $3\frac{1}{2}$ digit to read ± 1999 counts.

Power Supply : 230V ±10%@50 Hz