

## UNITECH SCALES AND MEASUREMENTS PVT. LTD.

## **Control Lab Equipment -**

## Pressure to Current Measurement Trainer



www.unitechscales.com

E-mail: - support@unitechscales.com; sales@unitechscales.com

Mobile no : - +91-98452 22919 (Mr. Prasanna Kumar N.M) Mobile no : - +91-98450 70453 (Mr. Keshava Murthy M.N)

Phone no: - +91-80-2836 6999 | Fax no: - +91-80-2836 6745

Pressure to Current (P to I) Trainer: This setup comprises of pressure chamber fitted on a base board. A pressure transducer and bourdon pressure gauge are fitted to the chamber. Digital pressure indicator with transmitter output is provided to display the pressure sensor by the pressure transducer. Transmitter output 4 to 20mA can be measured by a current meter. Foot air pump is provided to build the pressure.

Model : UITM-17

Pressure Source : Air tank fitted with pressure gauge.

Pressure Transmitter : Strain gauge/piezo resistive type.

: Pressure transmitter with 4-20mA output for 0 to 15 PSI.

Indicator : 3½ digit LED display.

Display : Current 4-20mA

: Pressure-0-30-0 Psl

Resolution : 0.1mA and 0.1PSI

Power Supply : 230V 50 Hz

Accessories Supplied : Foot air pump to build pressure